

RCA REMOTE SLIM CONVERTER



INSTRUCTION MANUAL

ENFORCING

Used on CD/DVD players that do not have RCA output.

FEATURES

Converts the speaker level to RCA.

Remote control output for operation of amplifiers with over current protection and short circuit with earth.

SPEAKER INPUT

(Black/Black and White thread)

Connect to the output to the player speaker



RCA OUTLET

Connect to the amplifier or crossover/processor

INPUT 12V (Red thread)
Connect to positive battery

GND (Black Thread)
Connect to negative battery

REMOTE OUTPUT (Blue Thread)
Connect to the remote control of the remote amplifier or sequencer